

2025



HI-TECH
FOR GAMERS

HI-TECH MANUAL
ENGLISCH

THANK YOU!

The time has come—here is your new HI-TECH gaming system! First of all, thank you very much for your purchase! To make your setup as easy as possible, we have put together this brochure to answer your questions and provide guidance. Please read it carefully to ensure nothing stands in the way of your gaming experience!

Flexible Business Hours:

If you would like a personal delivery or pickup of a new device, we kindly ask you to contact us to arrange an appointment.

You can reach us by phone at:

+43 7229 61000

or by E-Mail at:

office@hi-tech.at

Our address is:

HI-TECH for Gamers GmbH

Johann Roithner-Straße 131, A-4050 Traun

2

CONTENTS

THANK YOU! <small>Contact</small>	2
DAMAGES & RETURNS	3
ATTENTION! <small>Safety Instructions</small>	4
MONITOR CONNECTIONS	4
PACKAGING MATERIALS / ACCESSORIES	5
OPERATING TEMPERATURE & CLEANING	5
CHANGING WINDOWS 11 LANGUAGE	6 – 7
WATER COOLING <small>Maintenance</small>	8
IMPRINT	9

DAMAGES & RETURNS

DAMAGES

Please check the package for external damage immediately upon receipt. If you notice any transport damage (e.g., significant tears in the outer carton), accept only after noting "Package damaged" in the signature field. This field is part of the driver's package scanner. Make sure to point out the damage to the driver and also take photos of it. Send these to us immediately - so we can assist you in protecting your rights.

If the driver refuses to allow you to make a note in the signature field, please refuse acceptance of the package and inform us immediately!

Occasionally, we conduct test shipments for quality assurance to further improve our standards. In such cases, a red or purple sticker labeled SHOCKWATCH will be on the package. Please check whether the indicator on this sticker is white or red. If it is red, note on the delivery receipt—even if the package appears undamaged—that the indicator is red and the shipment was therefore handled improperly.

RETURN AND PICKUP SERVICE

In case of any issues, we offer - as a special service - a transport-insured pickup of your device from your home during regular business hours. Please ensure that the device is securely packaged for transport. It is strongly recommended to use the original box and packaging materials. Otherwise, improper packaging may cause unnecessary transport damage, for which neither we nor the carrier can be held responsible.

Therefore, please make sure the system is packed securely, filling all empty spaces to prevent possible damage during shipping.

Since different models (gaming PCs, laptops, etc.) are packaged differently, we ask that you contact us at **service@hi-tech.at** for detailed instructions. This also allows us to coordinate the return process together.

ATTENTION!

Please follow these safety instructions:



WARNING: No objects or liquids should enter the interior of the computer.



CAUTION: When opening or removing the protective case, you are exposed to dangerous voltages and other risks. Be especially careful and ensure that your PC is disconnected from the power supply. In case of misuse or an accident (e.g., dropping the device), contact our HI-TECH for Gamers maintenance personnel immediately.

MONITOR CONNECTIONS

The monitor connections are located on the back of your PC.

GRAPHICS CARD / MONITOR CONNECTIONS

Please connect your monitor to the available graphics card ports (horizontal) and not to the motherboard ports (vertical).



Illustration

PACKAGING MATERIALS / ACCESSORIES

Please observe the instructions found on the sides, front, and back of your gaming PC system.

Illustration



Remove all packaging material completely, including from the inside of the case!

To do this, first remove the side panel. Detailed instructions can be found at hitech-gamer.com/en/Quickstart-guide/

Illustration



5


OPERATING TEMPERATURE & CLEANING

Do not expose the PC system to extreme temperatures (room temperature only). To ensure the longevity of your gaming PC system or laptop, we recommend performing regular internal cleaning. Dust easily accumulates on the heatsinks and fans, which can lead to overheating and damage during operation.


CHANGING WINDOWS 11 LANGUAGE^[1]

An Internet connection is required!

1. Right-click the Windows icon in the lower-left corner and select "Settings."




2. Go to "Time & language" and then "Language & region."





CHANGING WINDOWS 11 LANGUAGE^[2]

3. Go to "Language."
Select your desired language.



4. Then go to "Administrative language settings."

5. Click on "Copy settings."



6. Check "Welcome screen and system accounts" and "New user accounts."
Confirm by clicking "OK."
7. A restart is required.

WATER COOLING

FULLY WATER-COOLED PC SYSTEMS

Please follow these steps when refilling the water in your cooling system:

1. Turn off the PC and disconnect it from the power supply.
2. Remove the left side panel.
3. Loosen the marked screw by hand and carefully open it!
4. Fill the coolant until the reservoir is 90% full.
5. Close the reservoir and start the PC.
6. Ensure that no water leaks from the screw during operation. If it does, tighten the screw further.



Full water cooling

Illustration

CPU WATER COOLING

Unlike fully water-cooled PC systems, these systems do not require water refilling.



CPU water cooling

Illustration



HI-TECH
FOR GAMERS

HI-TECH for Gamers GmbH

Johann Roithner-Straße 131, 4050 Traun, Tel +43 7229 61000

HI-TECH MANUAL Version 10/2025

Copyright© 2025 by HI-TECH for Gamers GmbH. All rights reserved.

As part of our continuous product improvements, we reserve the right to make technical and design changes.
Typographical errors excepted. Suggestions for improvement can be sent via email to marketing@hi-tech.at.